


















# Package Contents

**Machine**

 Front Assembly * 1	 M4X12 Screw * 17	 M2.5 Allen Key * 1
 Left Y-Axis Assembly * 1	 M4X16 Screw * 2	 M3.0 Allen Key * 1
 Right Y-Axis Assembly * 1	 Machine Key Set * 1	 USB Cable * 1
 Rear Panel Assembly * 1	 Coupling * 2	 Power Cable * 1
 X-Axis Assembly * 1	 Laser Goggle * 1	 Power Adapter * 1
 Motor Extension Shaft * 1	 Brush * 1	




**Laser module**

 LB-20A Laser Module * 1	 Air Assist Nozzle * 1
 Laser Shield * 1	 Replacement Lens * 1
 Replacement Nut * 1	 Replacement O-Ring * 1
 Lens Tool * 1	 Lens Finger Guard * 1

**Air Pump**

 AlgoLaser Air pump(AAP 1.0)	 Air Pipe * 1
--	---

**Consumable**

 Plywood * 1 (340mm*220mm*3mm)	 Acrylic * 1 (175mm*122.5mm*3mm)
 Metal Card * 3 (86mm*54mm*0.2mm)	